

## AERIAL LIFTS

**BEFORE YOU OPERATE THIS LIFT, READ, UNDERSTAND AND OBEY ALL THE SAFETY RULES AND OPERATING INSTRUCTIONS IN THE OPERATOR'S MANUAL LOCATED IN THE BLACK PLASTIC STORAGE BOX ON THE EQUIPMENT**

***FAILURE TO FOLLOW THESE INSTRUCTIONS COULD RESULT IN INJURY OR DEATH***

- If the person receiving this handout will not be the user of the equipment, forward these instructions to the operator
- Always perform a pre-operation inspection and function test prior to use
- This examination should be complete and all potential deficiencies corrected before further use
- Do not use this machine if physical damage occurs or if controls are not functioning properly

For any safety or mechanical questions contact **AACTION RENTS at 707-838-4373**

### **WARNING**

- Any piece of equipment can be dangerous if not operated properly
- YOU are responsible for the safe operation of this equipment
- Do not remove, defeat, deface or render inoperable any of the safety devices or warnings on this equipment
- If any safety devices or warnings have been removed, defeated, defaced or rendered inoperable, do not use this equipment

**OSHA LAW REQUIRES A FULL BODY HARNESS WITH LANYARD ATTACHED TO THE LANYARD ANCHORAGE BE WORN AT ALL TIMES BY EVERY PERSON IN THE PLATFORM**

### **SAFETY RULES**

- Maximum platform capacity is 500 pounds
- Maximum occupants are 2 persons
- Adjust travel speed to suit conditions
- Always clear area before any movement of machine vertically or horizontally
- Do not raise or extend the boom unless the machine is on a firm level surface
- This machine is **not** electrically insulated and **will not** provide protection from contact with electrical current
- Maintain a safe distance from any power lines
- Do not use the machine as a ground for welding
- Do not raise the boom in strong or gusty winds
- Do not drive the machine on or near uneven terrain, unstable surfaces or other hazardous conditions with the boom raised or extended
- Do not push off or pull toward any object outside the platform
- Maximum allowable side force is 150 pounds
- Do not place or attach overhanging loads to any part of this machine
- Do not place ladders or scaffolds in platform or against any part of this machine.
- Do not use machine on a moving or mobile surface or vehicle
- Do not operate the machine during lightning, or in a storm
- Do not alter or disable the machine components that in any way that affect safety and stability
- Do not climb down from the platform when raised
- Do not tow platform – for longer distance moves the lift should be transported by truck or trailer
- Do not work under or perform any maintenance on the lift while the machine is in a raised position unless a safety bar is in position

### **Control Panel Power Switch (on/off)**

- Keep this switch turned to “Off” position at all times except when operating machine to prevent accidental actuation of machine controls

### **Battery**

- Battery acid is extremely corrosive and can cause serious burn
- Wear proper eye and facial protection as well as appropriate protective clothing
- If battery acid is splashed on skin flush away acid with water and seek medical attention
- Do not smoke near batteries
- Keep flames and sparks away

### **Battery Maintenance**

- Check battery water daily and fill as necessary
- Charge batteries approximately 50% of the time the electrical functions were used
- Monitor batteries during charging. Do not allow batteries to over-charge and boil; do not remove caps

### **DISCLAIMER**

Customers must read, utilize and understand manufacturer's safety and operating instructions prior to equipment operation. Rental Center may provide supplemental information; however, such supplemental information should not be used by Customer if it is in conflict with manufacturer's instructions. Ordinary rules of safety require machinery or equipment to be operated only in the manner and for the purposes for which it was designed.